

Universal Materials Database

Jodi Cooley
Southern Methodist University

Need

- There exists an extensive amount of information on backgrounds of various materials in the low background community.
- There is a desire to share that information across collaborations in an efficient manner.

Proposed Solution

- A community database software package.

Options

- At the last meeting we discussed some options:
 - ILIAS radiopurity database (Pia Loaiza, LSM France)
 - Low Background Facility Database (James Loach, LBNL)
 - open source software
 - tested by LBF and MAJORANA

LBF Database Details

- Engine - Apache CouchDB
- Search Facility - Apache Lucene
- Application Framework - CouchApp
- Front End - Persephone

MAJORANA
Material Assay
Database



James Loach
Feb.

MAJORANA
Material Assay
Database

tin|



- ⊞ Tin, LANL
- ⊞ Tin, LANL
- ⊞ Tin, Canberra

MAJORANA Material Assay Database



☐ Tin, LANL

sample	description	
	Tin, 99.9998% purity	
measurement	technique	results
	Gamma	
	U chain	< 1.7 mBq/kg
	Th chain	< 3.1 mBq/kg
	K-40	25 (14) mBq/kg
	Co-60	< 1.5 mBq/kg

⊕ Tin, LANL

⊕ Tin, Canberra

MAJORANA Material Assay Database



[-] Tin, LANL

sample	description	Tin, 99.9998% purity		
	source	Adam Montoya, LANL		
	owner	LANL		
	set	Majorana		
	mass	710 g		
	geometry	Block of metal		
measurement	technique	Gamma		
	institution	LANL / WIPP		
	date	5 / 2010		
	practitioner	Steve Elliot, LANL (elliotts@lanl.gov)		
	description	The tin was placed inside two nested plastic bags and put inside the WIPP-n cavity. Background spectrum 66.78 days.		
	count length	99.2 d		
	detector	WIPP-n		
	results	U chain	< 1.7	mBq/kg
		Th chain	< 3.1	mBq/kg
		K-40	25 (14)	mBq/kg
		Co-60	< 1.5	mBq/kg
data	reference	Majorana report M-TECHDOCDET-2010-110		
	entry by	James Loach (jcloach@lbl.gov)		

- [+] Tin, LANL
- [+] Tin, Canberra

tin



☐ Tin, LANL

sample

descripti

source

owner

set

mass

geometr

measurement

techniqu

institutio

date

practition

descripti

count ler

detector

results

data

reference

entry by

Export

✕

Copy and paste into Excel or similar.

```
"Tin, LANL", "U chain", "<", "1.7", "mBq/kg", "Th chain", "  
<", "3.1", "mBq/kg", "K-40", "25", "14", "mBq/kg", "Co-60", "  
<", "1.5", "mBq/kg"  
"Tin, LANL", "Li", "<", "0.007", "ug/g", "Be", "  
<", "0.004", "ug/g", "Na", "<", "9", "ug/g", "Mg", "<", "1", "ug/g", "Al", "  
<", "1", "ug/g", "K", "<", "10", "ug/g", "Ca", "<", "6", "ug/g", "Sc", "  
<", "0.1", "ug/g", "Ti", "<", "1", "ug/g", "V", "<", "2", "ug/g", "Cr", "  
<", "5", "ug/g", "Mn", "0.15", "ug/g", "Fe", "60.6", "ug/g", "Co", "  
<", "1", "ug/g", "Ni", "  
<", "5", "ug/g", "Cu", "24.4", "ug/g", "Zn", "2.5", "ug/g", "Ga", "  
<", "0.3", "ug/g", "As", "<", "0.2", "ug/g", "Se", "<", "0.3", "ug/g", "Rb", "  
<", "0.1", "ug/g", "Sr", "<", "0.09", "ug/g", "Y", "  
<", "0.002", "ug/g", "Zr", "<", "0.007", "ug/g", "Nb", "  
<", "0.006", "ug/g", "Mo", "<", "0.3", "ug/g", "Rh", "  
<", "0.006", "ug/g", "Pd", "  
<", "0.03", "ug/g", "Ag", "231", "ug/g", "Cd", "<", "0.04", "ug/g", "Sb", "  
<", "37", "ug/g", "Te", "<", "0.03", "ug/g", "Cs", "<", "4", "ug/g", "La", "  
<", "0.6", "ug/g", "Ce", "<", "0.5", "ug/g", "Pr", "<", "0.6", "ug/g", "Nd", "  
<", "0.01", "ug/g", "Sm", "<", "0.03", "ug/g", "Eu", "  
<" "0.05" "ug/g" "Gd" "<" "0.02" "ug/g" "Th" "
```

James Loach (jcloach@lbl.gov)

☐ Tin, LANL

☐ Tin, Canberra

Progress and Plans

- At SMU we have been trying to install the package.
 - CouchDB installs without problems
 - The other packages have various issues that we are still working to resolve.
- We are putting together a small group of people to assess the feasibility of using the LBF database and model on a larger scale. (technical)
- If successful, we plan to open the working group to a larger number of people to plan the database and write a white paper on the project.